



The three suction surfaces of Clair 5000 suck the air and clean by a total of 5 filter stages . 96% of the air leave the system to the top and 4 % by the plenum downward. The dust from grinding is blown towards to the filter, the plenum will be placed over the object you work on. The slight air flow moves the dust to the Filter surfaces of Clair 5000.

Different by painting:

To protect the object from dust the plenum will be placed parallel to the painting surface.

Through the blow-down is crated an Air curtain as a barrier that prevents that dust can reach the object, or paint can pass in the workshop area

The Clair 5000 has 2 connectors for exhaust hoses. This allows taking air outward during paint, to respect all national rules for painting. The Clair 5000 complies with current CE and ATEX standards.



facts:

warantiy 2 years

powerconsumption: 400 V 1,35 kW noise at all in db(A): 69 dB(A) aircapacity: 4.900 m3/h

dimensions: 900 x 795 x 2.650 mm

Extension:with 500 mm elements, up to 4,150 mm

weight in total: ca. 240 kg

Various models and other dimensions on request

Modular and convertible



The ClAIR 5000 in use

The mobile and energy-saving circulating air extraction system ensures clean air in your workshop. Whether fillers, painting or sanding - the Clair 5000 improves your quality of work.

Dust and solvents are filtered out reliably from your environment.

Accessories

CLAIR 5000

prefilterr

lifetime: 1-3 month set with 3 pcs. 7,50€

main filter

lifetime 3-6 month set with 3 pcs 117.-€

filter cassette for micro dust

filter cassette for micro dust Lifetime 9-12 months price: 130, -€

active carbon filter cell

Life approximately 24 months, depending on the application price 1.500, -€

pocketfilter

renew together with activated carbon filter price: 39, -€

The illustrations and specifications are subject and could be changed without notice





